

# LXNAV

## CAN remote

control stick

Installation manual Version CAN 1.0




## **1 Technical Data**

- Power input 8-18V DC
- Consumption at 12 V: 60mA
- Weight 300g

## 2 Installation

LXNAV remote stick is connected to CAN bus through Remote-Can adapter.



Be careful, that connect correct color wire to pin, which is marked with same color.

PTT wires are connected to radio, SC is connected to Speed to fly input of vario unit.



Remote stick will not operate, until is registered on device. Remote stick can be registered under setup-hardware-Remote stick. Registration must be done on each unit (S80 and S80D)

### 3 Functions

